

# ASSEMBLY INSTRUCTIONS

## WB-10P 10 CUBIC FT. WHEELBARROW

### TOOLS NEEDED

Adjustable wrench and standard bit screwdriver.



### SUGGESTIONS

Work in a clean and level work area.

Place all loose bolts, nuts, and washers in a small container.

Do not wrench tighten nuts until entire wheelbarrow is assembled.

Use washers, lock washers, and nuts in the order shown in the diagram below.



### ASSEMBLY

1. Set the tray on it's side, insert 3" bolts through all four holes in the tray bottom, then slide the nylon retention washers all the way onto the bolts so they stay in place.
2. From the inside of the tray, insert two 0.75" bolts through the holes at the front of the tray and fasten tops ends (40° bend) of tray braces to the tray. Loosely fasten with washers, lock washers, and nuts.
3. Lay the tray down on it's top so that bolts are pointing up.
4. Position handles properly and slide onto bolts.
5. Position short cross brace (to the front of the tray) and long cross brace (to the rear of the tray) and slide them onto the bolts.
6. Position legs properly and slide onto bolts, then secure parts loosely using flat washers, lock washers, and nuts.
7. Attach the leg brace to the back of both legs loosely using four 0.75" bolts, flat washers, lock washers, and nuts.
8. Attach nose guard loosely to the outside front of the handles using four 2.25" bolts, washers, lock washers, and nuts.
9. Insert 3" bolts through the four holes in the top front of the handles. The two bolts closest to the nose guard must first go through the holes on the bottom end of the tray braces.
10. Place the axle plates and axle brackets over the bolts protruding through the bottom of the handles. The axle plates are to be flat against the handles, and the axle brackets are positioned so the axle can pass between the plates and brackets. Loosely fasten with washers, lock washers, and nuts.
11. Slide the axle through both axle brackets and then slide a wheel spacer, wheel, and large washer onto each end of the axle. Fasten with the cotter pins through the holes in the axle.
12. Tighten all nuts securely.

PK31010  
REV-1